

PAT

Photographic Activity Test (Per ISO 18916) Research Report

Customer: Piotr Tyrna
Company: PHU Beskid Plus
Address: ul. Towarowa 3
43-400 Cieszyn
Poland

Date: 9/11/14
Job: 2234

Material: Archival Board Castello-white side

Silver Image Interaction

Density change of control:	-1.15
Upper pass/fail limit:	-0.92
Density change of material:	-1.32
Lower pass/fail limit:	-1.38

Density change caused by material must fall between upper and lower limits ($\pm 20\%$ change in control)

Material pass/fail: Pass
Reason: Within image interaction limits

* Control material in Whatman No. 1 filter paper

Andrea Venosa
Operator

Note: The PAT should always be used in conjunction with ISO 18902, *Imaging Materials - Processed Photographic Films, Plates, and Papers - Filing Enclosures and Storage Containers*, when selecting enclosures.

Gelatin Staining

Density change of control:	0.09
Stain limit:	0.17
Density change of material:	0.15

Staining caused by material must be less than stain limit (control +0.08)

Result: Pass
Reason: Less than stain limit

Mottling of Image Interaction Detector

Visual assessment of uniform action

Result: Pass

Overall Performance - Must pass all criteria:

Pass

This certificate is valid for this specific lot of product until any date, or for any subsequent lot of this product produced until: **9/11/15**
This certificate is void upon any change in product formulation, or change in manufacturer or manufacturer suppliers.



Photographic Activity Test (Per ISO 18916)
Research Report

Customer: Piotr Tyrna
Company: PHU Beskid Plus
Address: ul. Towarowa 3
43-400 Cieszyn
Poland

Date: 9/11/14
Job: 2234

Material: Archival Board Castello-gray side

Silver Image Interaction

Density change of control:	-1.15
Upper pass/fail limit:	-0.92
Density change of material:	-1.32
Lower pass/fail limit:	-1.38

Density change caused by material must fall between upper and lower limits ($\pm 20\%$ change in control)

Material pass/fail: Pass
Reason: Within image interaction limits

* Control material in Whatman No. 1 filter paper

Andrea Venosa
Operator

Note: The PAT should always be used in conjunction with ISO 18902, *Imaging Materials - Processed Photographic Films, Plates, and Papers - Filing Enclosures and Storage Containers*, when selecting enclosures.

Gelatin Staining

Density change of control:	0.09
Stain limit:	0.17
Density change of material:	0.14

Staining caused by material must be less than stain limit (control +0.08)

Result: Pass
Reason: Less than stain limit

Mottling of Image Interaction Detector

Visual assessment of uniform action

Result: Pass

Overall Performance - Must pass all criteria: Pass

This certificate is valid for this specific lot of product until any date, or for any subsequent lot of this product produced until: **9/11/15**
This certificate is void upon any change in product formulation, or change in manufacturer or manufacturer suppliers.